

# TiVo Home Network Settings (Non-MoCA)- Article no. 1399

---

**Self-Service Support Alert: this article is available for customers on [help.astound.com](http://help.astound.com)**

## Resolution Steps

---

[Expand All](#) | [Collapse All](#)

### Wireless Setup for the First Time

## Connect wirelessly to the internet (no MoCA) with a Wireless G Adapter

1. Make sure the **Wireless G adapter** is open so that it forms an **L shape** (90 degree angle)
2. Insert **one end** of the **USB cable** into the **Mini USB port** on the adapter and the **other end** into a **USB port** on the **back** of the **TiVo**
3. Go to **TiVo Central | Settings & Messages | Settings | Network** and see the **Network connection details** reads **No Connection**
4. Select **Change Network Settings** to set up a network on a **new router**
5. On the **Change Network Settings** page, choose **Connect Using Wireless G Adapter** and press **Select** on the remote
6. On the **Wireless Network Name** screen, highlight the **correct Network name (SSID)** and press **Select** on the remote
  - If you can't **find** the correct SSID, choose **Enter Network Name** and press **Select** on the remote to **manually** enter the SSID

### Quick Tips

**Add a Space**

select (SPC) at the top of

**Capital Letters**

select (ABC) at the top of

use the **Thumbs Up** on

**Special Characters**

select (SYM) at the top of

**Delete a Character**

use the Rewind key(??)

1. On the **Enter Network Password** screen, enter the **correct** password using the **Quick Tips** above, then highlight **Done** and press **Select** on the remote

- When finished, highlight **Done entering network password** and press **Select**
2. The TiVo detects the **Wireless G Adapter** and displays the **IP Address** screen

- Select **Get Automatically from a DHCP server (typical)**
- Select **No (or not sure)** for the **DHCP Client ID**

**Note:** if **Get Automatically from a DHCP server (typical)** is not displayed, **power cycle** the **Adapter** and **repeat steps 3 through 7**

## **Wireless Setup: Change Existing Connection**

1. Make sure the **Wireless G adapter** is open so that it forms an **L shape** (90 degree angle)
2. Insert **one end** of the **USB** cable into the **Mini USB port** on the **adapter** and the **other end** into a **USB port** on the **back of the TiVo**
3. Go to **TiVo Central | Settings & Messages | Settings | Network** and see the **Type** listed as **Wireless Adapter**
4. Select **Change Network Settings** to set up a network with a **new router** or to **reset the network connection**
5. On the **Change Network Settings** page, choose **Connect Using Wireless G Adapter** and press **Select** on the remote
6. On the **Wireless Network Name** screen, highlight the **correct Network Name (SSID)** and press **Select** on the remote
  - If you can't **find** the correct SSID, choose **Enter Network Name** and press **Select** on the remote to **manually** enter the SSID

### Quick Tips

<b>Add a Space</b>	select (SPC) at the top of the screen
<b>Capital Letters</b>	select (ABC) at the top of the screen
<b>Special Characters</b>	use the <b>Thumbs Up</b> on the remote
<b>Delete a Character</b>	select (SYM) at the top of the screen
	use the <b>Rewind</b> key(??)

1. On the **Enter Network Password** screen, enter the **correct** password using the **Quick Tips** above, then highlight **Done** and press **Select** on the remote
  - When finished, highlight **Done entering network password** and press **Select**

2. The TiVo detects the **Wireless G Adapter** and displays the **IP Address** screen

- Select **Get Automatically from a DHCP server (typical)**
- Select **No (or not sure)** for the **DHCP Client ID**

**Note:** if **Get Automatically from a DHCP server (typical)** is not displayed, **power cycle** the **Adapter** and **repeat steps 3 through 7**

## **Wired Setup: Using an Ethernet Cord to Connect a TiVo to the Internet**

1. Connect **one end** of an **Ethernet cable** to an **Ethernet port** on the **router** and connect the **other end** to the **Ethernet port** on the **back of the TiVo**
  2. For **4 Tuners, 2 Tuners, Single Tuners, and Minis** on **TiVo Experience 3**
    - Go to **TiVo Central | Settings & Messages | Settings | Network** and select **Change Network Settings**
    - Follow the **on-screen instructions** to enter the **Network Settings**
    - The TiVo detects an **Ethernet** connection and displays the **IP Address** screen
- Select **Get Automatically from a DHCP server (typical)**

3. For **4K 6 Tuners, 6 Tuners** and **Minis** on **TiVo Experience 3**

- Go to **TiVo Central | Settings & Messages | Network Settings** and select **Change Network Settings**
- Select **Change Network Settings**
- Make sure **Ethernet** is **On** and **MoCA** is **Off**
- Select **IP Address** and select **Get automatically from a DHCP server (typical)**

4. **4K 6 Tuners, 6 Tuners , 4K Minis,** and **Minis** on **TiVo Experience 4**

- Go to **TiVo Central | left arrow to Menu | Settings | Network Settings**
- Select **Change Network Settings**
- Make sure **Ethernet** is **On** and **MoCA** is **Off**
- Select **IP Address** and select **Get automatically from a DHCP server (typical)**

Online URL: <https://agentx-astound-kb-qa.hgsdigital.com/article.php?id=146>