Adding Init Strings for Windows Dialup- Article no. 2246

Self-Service Support Alert: this article is available for customers on help.astound.com

Introduction

Init strings are commands that help a **Dialup modem** establish a connection and **stay connected**

Resolution Steps

Windows 10

- Go to **Start | Control Panel | Hardware and Sound | Device Manager | Devices and Printers**
- Click the arrow to the left to **expand the modems**
- **Right click** on the dial-up modem
- Go to **Properties | Advanced |** and enter the appropriate init string from this list

Online URL: https://agentx-astound-kb-qa.hgsdigital.com/article.php?id=463